# SIMPLE-DISPENSER INSTALLATION GUIDE

For printer models:

GL 4xxe Series

Read this Installation Guide before and during the installation
of the above accessory. Keep this Installation Guide handy
for future reference.

1　General

1.1　Important information

This quick guide provides important information on how to setup your new SATO product.

Be sure to read this quick guide thoroughly before using this printer. It is an integral part of the product and should be kept in the immediate vicinity of the device and available to the operating staff.

1.2　Limitation of liability

All information in this manual have been compiled under due consideration of federal standards and regulations.

The manufacturer will not be held liable for damage resulting from:

- Disregarding these instructions
- Unintended use of the printer
- Unauthorized technical modifications
- Use of unapproved spare parts
- Use of unapproved consumables

FCC WARNING
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

1.3 Explanation of symbols

This instruction manual uses various warning icons to help you understand the safe operation of your printer. Explanations of the icons are below.

WARNING!

Indicates neglectful or erroneous use may cause irreparable damage to the product, serious injury to the operator, or worse.

CAUTION!

Indicates a specific point where caution should be used. The graphic within the triangle will indicate the specific issue, i.e.; the sign on the left indicates a caution for potential electrical shock.

CAUTION!

Indicates a potentially hazardous situation which, if not avoided, may result in damage to your product or host equipment.

NOTE!

Emphasizes useful tips or recommendations for efficient and smooth operation of your printer.

1.4 Contact and Document Information

SATO GROUP OF COMPANIES	
International Headquarters	**Americas**
SATO INTERNATIONAL PTE. LTD 438A Alexandra Road #05-01/04, Alexandra Technopark, Singapore 119967 Phone: 65-6271-2122 Fax : 65-6271-2151 Email: sales@sato-int.com	SATO INTERNATIONAL AMERICA, INC. (Regional HQ) 10350 Nations Ford Road Suite A, Charlotte, NC 28273 Phone: 1-704-644-1650 Fax: 1-704-644-1662 Email: satosales@satoamerica.com
Americas	
SATO AMERICA, INC. 10350 Nations Ford Road Suite A, Charlotte, NC 28273 Phone: 1-704-644-1650 Fax: 1-704-644-1662 Email: satosales@satoamerica.com	SATO LABELING SOLUTIONS AMERICA, INC. 1140 Windham Parkway, Romeoville, Illinois 60446 Phone: 630-771-4200 Fax : 630-771-4210 Email: sales@satolabeling.com Horticultural Division 930 Jimmy Ann Drive Daytona Beach, FL 32117 Phone: 1-386-274-5566 Fax: 1-386-274-5599
Europe	
SATO INTERNATIONAL EUROPE N.V. (Regional HQ) Leuvensesteenweg 369, 1932 Sint-Stevens-Woluwe, Brussels, Belgium Phone: 32(0)-2-788-80-00 Fax: 32(0)-2-788-80-80 Email: info@be.sato-europe.com	SATO UK LTD Valley Road, Harwich, Essex England Co12 4RR, United Kingdom Phone: 44-1255-240000 Fax : 44-1255-240111 Email : enquiries@satouk.com
SATO LABELLING SOLUTIONS EUROPE GmbH Ersheimer Straße 71, 69434 Hirschhorn, Germany Phone: 49-6272-9201-324 Fax: 49-6272-9201-399	SATO POLSKA SP Z O.O. Ul. Wroclawska 123, 55-015 Radwanice K/Wroclawia, Poland Phone: 48-71-381-03-60 Fax: 48-71-381-03-68 Email: info@sato-europe.com
SATO FRANCE SAS Parc D'Activities - Rue Jacques Messager - 59175 Templemars, France Phone: 33-3-20-62-96-40 Fax: 33-3-20-62-96-55	SATO IBERIA S.A. Dels Corrals Nous, 35-39, Pol. Can Roqueta, 08202 - Sabadell, Barcelona, Spain Phone: 34-93-492-5750 Fax : 34-93-786-3451
Asia Pacific & Oceania	
SATO INTERNATIONAL ASIA PACIFIC PTE. LTD. (Regional HQ) 438A Alexandra Road #05-01/04, Alexandra Technopark, Singapore 119967 Phone : 65-6271-5300 Fax : 65-6273-6011 Email: sales@sato-int.com	SATO AUTO-ID MALAYSIA SDN. BHD. No.25, Jalan Pemberita U1/49, Temasya Industrial Park Section U1, 40150 Shah Alam, Selangor Darul Ehsan, Malaysia Phone: 60-3-7620-8901 Fax: 60-3-5569-4977 Email: sales@satosms.com.my
SATO ASIA PACIFIC PTE. LTD. 438A Alexandra Road #05-01/04, Alexandra Technopark, Singapore 119967 Phone: 65-6271-5300 Fax: 65-6273-6011 Email: sales@satoasiapacific.com	SATO AUTO-ID (THAILAND) CO., LTD. 292/1 Moo 1 Theparak Road, Tumbol Theparak, Amphur Muang, Samutprakarn 10270 Phone: 662-736-4460 Fax: 662-736-4461
SATO SHANGHAI CO., LTD. 307 Haining Road, ACE Bldg, 10th Floor, Hongkou Area, Shanghai, China 200080 Phone: (86) 021- 63068899 Fax: (86) 021- 63091318	SATO AUSTRALIA PTY LTD. 1/1 Nursery Avenue, Clayton Business Park (1508 Centre Road) Clayton VIC 3168, Melbourne, Australia Phone: 61-3-8814-5330 Fax: 61-3-8814-5335
SATO NEW ZEALAND LTD 30 Apollo Drive, Mairangi Bay PO Box 305-031, North Shore, Auckland, New Zealand Phone: 64-9-477-2222 Fax: 64-9-477-2228	For a full list of all SATO offices, refer to www.satoworldwide.com

Extensive contact information of worldwide SATO operations can be found on the Internet at
**www.satoworldwide.com**

Version: SI-GL4xxe-01rA-05-06-07-SSDIG © Copyright 1994 – 2007

GL4xxe Simple-Dispenser Installation

The Simple Dispenser comes with its own front cover to replace the factory-installed front cover of the GL4xxe series printer. Follow the procedures below to install the Simple Dispenser.

1. Make sure the printer is OFF and disconnected from the power supply.
2. Lift up the side cover to access the original housing cover (1).
3. Remove the original housing cover by unscrewing the thumbscrew (2) at the side of the printer.

Figure 1. Removing the existing front cover and preparing to install the replacement cover.

GL4xxe Simple-Dispenser Installation

4. Affix the dispenser (3) to the printer by plugging the white connector (4) into the complementary connector (4) on the printer.

5. Mount the simple dispenser by hooking it as shown in the illustration at the bottom of the page. Affix the dispenser with three supplied screws.

6. Mount the replacement front cover (5) onto the front of the printer, using the thumbscrew removed in Step 3 to screw it back into place. Note: Ensure that the cable is not pinched when you install the label cutter cover in place.

7. Restore power to the Printer and configure the printer to use the dispenser (see next page).

Hook

* When connecting Easy peel unit to printer body, hook it and slide it to left, and fix it with 3 screws.

Figure 2. Installing the dispenser and replacement front cover

GL4XXE SIMPLE-DISPENSER CONFIGURATION

Dispenser setup via the LCD Menu

1. Turn the printer ON and wait for it to initialize and go into ONLINE mode.
2. Press the **Line** Button to go to OFFLINE mode.
3. Press the **Function** Button to display the different menu icons

4. Select the Advanced Mode Menu and press the **Enter** Button.
5. Scroll to the Media Handling menu using the cursor buttons.
6. Once the simple dispenser has been installed correctly, this menu allows you to select the Peel-Off option to activate the dispenser's functionality. A **Remove Label** message will display on the LCD prompting label removal for each label that has been printed.
7. When done, go back to ONLINE mode after saving the new settings.

Figure 3. Setting the Media Handling option

SATO
DCS & Labeling Worldwide